



- SEDIMENT & EROSION CONTROL REFERENCE NOTES**
- CW1 Furnish and Install Concrete Washout Area, Use Output Washout or Filter-Applied Equal. See Notes on Sheet C-4.
 - CE1 Temporary BMP, Iowa SUDAS Standard Plan 906.120.
 - SFT1 - S22 Install SFT Fences in 10' Sections (max. length with J-Hook Ends, Iowa SUDAS Standard Plan 904.119).
 - IP1 - IP4 Inlet Protection, Temporary BMP.

Note:
Contractor shall construct temporary sediment traps (Iowa SUDAS Standard Plan 906.120) and inlet protection (Iowa SUDAS Standard Plan 904.119) prior to construction to limit site disturbance to less than 3 acres at any one time. Phased site shall be stabilized prior to disturbance or next phase of construction.

- PERMANENT STABILIZATION REFERENCE NOTES**
- 1 Line basin slopes with RECIB North American Green S150. Install per Manufacturer's recommendations. See "Extend Dry Detention Basin" detail on sheet 10 for seeding information.